

vergrendel door de velco op de zijkanten vast te kleven.

OPBOUW open het frame aan de achterzijde door de armen open te spreiden.



AFBOUW maak de velcro op de zijkanten los en vouw het frame toe.




WISSELEN DOEK zet het frame half open op de grond en plaats het doek op het frame. Plaats de vierkante velcrohechtingen op het doek op de velcrohechtingen van het frame.

ABC TexPop

ABC EXPO . BE

Draagbare & plooibare standen en displays
Layout, grootformaat print, fotografie en belettering





DEMONTAGE ouvrez le cadre à l'arrière en écartant les bras.

verrouiller en collant le velcro sur les côtés.



DEMONTAGE desserrez le velcro sur les côtés et pliez le cadre.



CHANGER TISSUE placez le cadre à moitié ouvert sur le sol et placez le tissu sur le cadre.

Placez les mailles velcro carrées sur la toile sur les mailles velcro du cadre.

ABC TexPop

ABC EXPO . BE

Stands & displays portables et pliables
Layout, impression grand format, photographie et lettrage





BUILD-UP open the frame at the back by spreading the arms open.

lock by gluing the velco to the sides.



UNBUILD loosen the velcro on the sides and fold the frame.



CHANGING PRINT

place the frame half open on the floor and place the cloth on the frame.



Place the square velcro stitches on the canvas on the velcro stitches of the frame.

ABC TexPop

ABC EXPO . BE

Portable & folding displays and stands
Layout, large format print, photography and lettering

